

U?

1	C109/DCD/GPO	FORCED_USB_BOOT	56	
2	C125/RING/GPO	HW_SHUTDOWN_N	55	
3	C107/DSR/GPO	GND	54	
4	C108/DTR/GPI	TXD_AUX/SPI_MOSI	53	
5	C105/RTS/GPI	RXD_AUX/SPI_MISO	52	
6	C106/CTS/GPO	V_AUX/PWRMON	51	
7	WAKE	RSVD_50	50	
8	RSVD_8	RSVD_49	49	
9	C103/TXD	GPIO_01/DVI_WA0	48	
10	C104/RXD	GPIO_02/DVI_RX	47	
11	SIMVCC	GPIO_03/DVI_TX	46	
12	SIMRST	GPIO_04/DVI_CLK	45	
13	SIMCLK	VBATT	44	
14	SIMIO	VBATT_PA	43	
		ML865C1		
15	ADC_IN1	RSVD_36	36	
16	RSVD_16	GND	35	
17	RSVD_17	RSVD_34	34	
18	VUSB	RSVD_33	33	
19	USB_D-	GPIO_05/GNSS_LNA_EN	32	
20	USB_D+	GPIO_06/SPI_CS	31	
21	GND	GPIO_07	30	
22	RSVD_22	GPIO_08	29	
23	GND	SPI_CLK		
24	RSVD_24			
25	RSVD_25			
26	RSVD_26			
27	GND			
28	RSVD_28			

<Value>